

Flugmodul System für MC-24

SPEKTRUM™

Inhaltsverzeichnis

Einleitung....3
Funktionen und Vorteile....4
Spezifikationen....4
DSM Flugmodule....4
Wichtige Modul Informationen....5
Antenneneinbau (intern)....6
Empfängereinbau....11
AR9000 Einbau....12
Bindung....14
Bindungsverfahren....14
Fail Safe Funktionen....17
SmartSafe....17
Empfängerfunktion....17
Nach dem Anschließen....17
Voreinstellung Fail Safe....18
Empfängerfunktion....18
Nach dem Anschließen....18
Programmierung SmartSafe (alle SPM Empfänger)....18
Programmierung Voreingestelltes Fail Safe (AR9000/9100)....18
Besonderheiten....19
Reichweitentest Modulsysteme....20
Durchführung des Reichweitentests....20
Flight Log mit AR9000....21
Einsatz des Flight Logs....21
EU-Konformitätserklärung....22
Garantie und Service Informationen....24
Warnhinweise....24
Garantiezeitraum....24
Beschränkte Haftung....24
Schadeneinschränkungen....25
Sicherheitshinweise....25
Fragen, Service....25
Überprüfung und Reparatur....25
Garantiereparatur....26
Kostenpflichtige Reparatur....26
Kontaktinformationen....26
Sicherheitshinweise....27

Horizon Hobby ist nicht der Hersteller und auch nicht der Vertriebspartner für MC24 Fernsteueranlagen. Wir haben das Produkt als Zubehör im Rahmen eines Zusatzmoduls entwickelt und in der Einsatzumgebung der MC24 auf Kompatibilität getestet.

Spektrum wird mit Einwilligung von Bachmann Industries Inc. verwendet

Einleitung

Spektrum Flugmodul Systeme bieten einen überragende Übertragungstrecke zu Ihrem Flugmodell. Sie brauchen nicht länger auf eine freie Frequenz warten oder sich Sorgen um Störungen durch schlechte Elektromotoren, Zündsystemen oder HF Störungen zu machen. Die Spektrum Modulsysteme basieren auf der originären DSM2 Technologie, der 2. Generation der Digitalen Spread Spektrum Modulation und bieten eine störungsfreie Verbindung zu dem Modell.

Das Modul arbeitet auf der Frequenz von 2,4GHz, dem weltweit eingesetzten ISM Frequenzband. Jedes Modul ist mit dem GUID, einem eindeutigen seriellen Digital Code versehen. Wenn ein Empfänger programmiert wird (mit dem Bindungsprozess), speichert er diesen Code und verarbeitet nur die Signale, die mit diesem Code markiert sind. Alle anderen Signale werden ignoriert.

Spektrum Flugmodule sind kompatibel mit allen Spektrum DSM2 Flugempfängern (nicht mit dem AR6000) und allen DSM2 2,4GHz Empfängern von JR.

Hinweis: Module sind nicht mit dem AR6000 Empfänger kompatibel.

Warnung: Wenn Sie das Modul mit einem AR6100 Empfänger einsetzen, sollte dieser nur Park- und Slowflyern sowie in kleinen Hubschraubern eingesetzt werden. Fliegen Sie diese Kombination nicht in großen Modellen insbesondere mit Besinmotoren oder großen elektrischen Antriebssystemen, da hier Signalverluste in größerer Entfernung auftreten können.

Funktionen und Vorteile

- Nutzt das 2,4GHz Band und ist international einzusetzen
- Kein Warten auf eine freie Frequenz
- Keine Störung durch Kanaldoppelbelegungen
- Völlige Sicherheit gegen fremde HF Quellen wie Mobiltelefone, WIFI oder andere Übertragungssysteme
- Immun gegen alle Störquellen im Modell (E-Motoren, Metallgetriebe, Zündsysteme)
- Wartungsfrei
- Fail Safe System für den Gaskanal (siehe Seite 17)

Spezifikation

DSM Flugmodule

Frequenz - 2400–2483MHz
Spektrale Kapazität - 40 Anlagen
Modulation - Direct Sequence Spread Spektrum
DSSS Kodierungsverstärkung - 18dB
Diversity - Multi Verbindung: Weg, Zeit und Frequenz
Strom Modul - 200mA
Strom Empfänger - 70mA
Empfängerspannung - 3.5-9V
Servokanäle - 9
Auflösung - 1024 mit 4x Oversampling

Wichtige Modulinformationen

- Stellen Sie unbedingt sicher, dass der Sender auf PPM18 programmiert ist. Ziehen Sie die Anleitung Ihrer Anlage heran, um dies einzustellen. Hinweis: Spektrum Module arbeiten nicht im PCM Mode oder einem anderen PPM Mode.

- Schalten Sie niemals das Modul ohne Antenne ein. Dadurch wird die Elektronik überlastet, was zu dauerhaften Schäden führt.

- Vor dem ersten Einsatz muss der Empfänger gebunden werden (siehe Seite 14 dieser Anleitung). Im Bindungsprozess wird der unverwechselbare Digitalcode (GUID) im Empfänger gespeichert. In diesem Prozess werden auch die Failsafe Daten gespeichert. Es wird empfohlen, dass System nach der Programmierung der Anlage nochmals zu binden, um sicherzustellen, dass die richtigen Failsafe Positionen vorhanden bleiben.

- Vor jedem Einsatz sollte die Reichweite getestet werden (sieh Seite 20), um sicherzustellen, dass das System korrekt arbeitet.

- Das Modul sollte mit dem AR6100 nur in Parkfliegern und kleinen Hubschraubern eingesetzt werden. Fliegen Sie diesen Empfänger in keinem Fall in größeren Modellen, besonders nicht mit Motorantrieb. Reflexionen des Signals können zu Signalausfällen in größerer Reichweite führen.

- Das Modul enthält die DSM2 Technologie und ist kompatibel zu allen DSM2 Empfängern. Damit kann das Modul mit dem DSM1 Empfänger AR6000 nicht betrieben werden.

Antenneneinbau

1. Entfernen Sie die Rückplatte.

2. Entfernen Sie die vorhandene Pin Leiste (zwei Schrauben).

3. Entfernen Sie den Modulrahmen (3 Schrauben).

4. Entfernen Sie das Antennenkabel (rot).



Antenneneinbau

5. Entfernen Sie die Druckplatte für die Antenne (3 Schrauben).



6. Entfernen Sie die Antennenaufnahme.



Antenneneinbau

7. Stecken Sie die 2,4GHz Antenne ein.



8. Bauen Sie die Druckscheibe ein.



9. Bauen Sie die Druckplatte mit zwei Schneidschrauben und einer Druckschraube ein.





Antenneneinbau

10. Bauen Sie den Rahmen wieder ein.



11. Schrauben Sie die neue Steckerleiste an.



12. Ziehen Sie den JST Stecker von der alten Steckleiste ab und stecken Sie es auf die neue auf.



13. Stecken Sie das 2,4GHz Modul ein.



Antenneneinbau

14. Verbinden Sie die Spektrum Antenne.
Warnung: Betreiben Sie das Modul nie ohne Antenne!

15. Fertiger Einbau.



16. Setzen Sie die neue Rückplatte ein.

Einbau des Empfängers

Das Modul ist mit allen DSM2 Empfängern kompatibel: AR500, AR6200, AR7000, AR7100, AR7100R, AR9000 und AR9100 für volle Reichweite sowie Parkfliegerempfänger AR6100, AR6100e und AR6300.

PARKFLIEGEREMPFÄNGER



• AR6100 • AR6100E • AR6300

Hinweis: Das optionale Flight Log (SPM9540) ist für die Empfänger AR7000, AR7100, AR7100R, AR9000 und AR9100 für die Aufzeichnung von Daten verfügbar. Sie können Daten zur HF Verbindung anzeigen lassen und so den Einbau des Empfangssystems optimieren. Details am Beispiel eines AR9000 finden Sie ab Seite 21.

DSM2 EMPFÄNGER MIT VOLLER REICHWEITE



• AR6200 • AR7000 • AR9000



• AR7100 • AR7100R • AR9100

Empfängereinbau

Einbau des AR9000

Der AR9000 besitzt zwei interne Empfänger und einen oder zwei externe Empfänger. Damit bietet er einen ausgezeichneten Schutz der HF Verbindung durch optimale Mehrwegtechnologie. Die beiden internen Empfänger befinden sich auf der Hauptplatine. Der externen Empfänger muss in einen der Ports am Gehäuse gesteckt werden, damit er arbeitet. Zusätzlich kann ein weiterer externer Empfänger an den verbleibenden Port angesteckt werden, so das maximal 4 Empfänger betrieben werden können. Durch die Platzierung dieser Empfänger an verschiedenen Orten im Modell befindet sich jeder der Empfänger in seiner eignen HF Umgebung, was zu einer herausragenden Wegdiversity führt (die Fähigkeit des Empfängers, das Signal aus allen Richtungen zu empfangen).



Hinweis: Der AR9000 kann nur mit mindestens einem externen Empfänger betrieben werden.

Wenden Sie beim Einbau des Empfängers die gleiche Methode an, wie bei einem konventionellen Empfänger. Wickeln Sie den Empfänger in Schaumstoff ein und befestigen Sie ihn mit Gummibändern oder Klettband. Bei Elektro oder Turbinenmodellen kann der Empfänger auch mit Doppelklebeband befestigt werden.

Die externen Empfänger werden an untersschiedlichen Stellen eingebaut, um die Weg Diversity zu optimieren. Jeder so abgesetzte Empfänger sieht seine eigene HF Umgebung und ist der Schlüssel zu der überragenden Sicherheit dieser HF Verbindung. Dies gilt auch für Modelle mit vielen induktiven Materialien, wie Gastrubinen, Schubrohre, Carbon, Resorohre und ähnliches, die Signale beeinflussen können.

Verwenden Sie Doppelklebeband, um die externen Empfänger zu montieren. Die Antennen sollten dabei einen Abstand von mindestens 51mm von den Antennen des Hauptempfängers haben. Ideal ist zudem der Einbau in der Form, dass die Antenne des externen Empfängers rechtwinklig zu den Hauptantennen ist. Wir haben herausgefunden, dass dies nicht unbedingt erforderlich ist. Verbindungskabel mit verschiedenen Längen sind erhältlich. In anspruchsvollen Flugzeugen hat sich die Platzierung der externen Empfängern an verschiedenen Orten des Modells bewährt. Dabei sollte der Abstand zu konduktiven Materialien so groß wie praktisch möglich sein.

Verlängerungskabel für externe Empfänger

6-inch (152mm)	SPM9010
9-inch (228mm)	SPM9011
12-inch (305mm)	SPM9012
24-inch (610mm)	SPM9013
36-inch (914mm)	SPM9014

Empfängereinbau

Dies ist eine typische Installation mit dem Empfänger an konventioneller Stelle und die externen Empfänger in der Spitze und im Leitwerk.



Bei einem Hubschrauber ist im Servorahmen in der Regel genug Platz für eine fachgerechte Installation.



Der externe Empfänger ist hier auf einem Stück durchsichtigen Kunststoff montiert.

Binden

Es ist erforderlich, das Modul mit dem Empfänger zu binden, so dass der Empfänger nur die Signale dieses spezifischen Empfängers verarbeitet. Ohne Bindung arbeitet das System nicht. Außerdem werden beim Binden die Fail Safe Positionen abgespeichert.

Die folgenden Instruktionen beziehen sich auf einen AR9000 Empfänger, sind aber sinngemäß auch auf die anderen Empfänger anzuwenden.

Bindungsverfahren

Der AR9000 empfänger muss mit dem Modul gebunden werden. Hier wird der spezifische serielle Digitalcode des Senders übermittelt. Nach dem Binden wird der Empfänger nur mit diesem Modul funktionieren bis er neu gebunden wird.

1. Bauen Sie das Empfänger System so auf und stecken Sie den Bindungsstecker in die Ladebuchse des Schalterkabels.



Hinweis: Das Binden mit einem Schalterkabel kann nur mit dreiadrigen Kabeln, wie bei SPM9530, durchgeführt werden.

Hinweis: Um ein System mit einem Regler mit BEC zu binden, stecken Sie bitte den Bindungsstecker in den Batterieport des Empfängers.

Binden

2. Schalten Sie den Empfänger ein. Hinweis: Die LED beider Empfänger müssen hochfrequent blinken und zeigen so an, dass sie zum Binden bereit sind.



3. Nehmen Sie die gewünschte Failsafe Position am Sender ein, normalerweise Gas auf Neutral und die andere Kanäle neutral.

Binden

4. Drücken und halten Sie den Bindungsknopf am Modul während Sie den Sender einschalten. Der Bindungsknopf blinkt und die Bindung erfolgt innerhalb der nächsten Sekunden. Das System ist fertig gebunden, wenn die LED an den Empfängern dauerhaft blinken.

5. Ziehen Sie den Bindungsstecker ab und bewahren Sie ihn gut auf.
6. Nach der Programmierung des Senders ist es wichtig, Ihr System noch einmal zu binden, damit die tatsächlichen Knüppelstellungen für die Fail Safe Funktion übertragen werden können.

Fail Safe Funktion

Alle Spektrum Empfänger verfügen über das SmartSafe System während der AR9000 über zwei Systeme verfügt, SmartSafe und Voreingestelltes Fail Safe.

SmartSafe

Dieser Fail Safe Typ wird für alle Elektromodelle und in den meisten Fällen auch für Verbrenner Modelle und Hubschrauber empfohlen.
SmartSafe funktioniert so:

> ***Hinweis***: Die Fail Safe Position beim Gas wird beim AR500 über die Gasknüppelposition definiert.

Empfängerfunktion

Wenn nur der Empfänger eingeschaltet ist (Sendersignal liegt nicht vor), fahren alle Servos in der Regel auf neutral und das Fahrwerk wird ausgefahren, bis auf das Gas. Diese Positionen werden beim Binden im Empfänger gespeichert. Zu diesem Zeitpunkt gibt es kein Ausgangssignal am Gas, um das armieren eines Reglers zu verhindern. Bei Verbrennermodellen bekommt das Gasservo kein Signal und bleibt in der vorhandenen Stellung.

Nach dem Anschließen

Schaltet man den Sender ein und verbindet sich dieser mit dem Empfänger können alle Kanäle normal betrieben werden. Nach der Verbindung und bei einem Signalverlust fährt SmartSafe nur das Gas Servo in die vorgesehene Fail Safe Position. Alle anderen Kanäle werden eingefroren. Wird die Verbindung wieder hergestellt, übernimmt das System sofort wieder die Kontrolle (weniger als 4ms).

> ***Hinweis***: Der AR500 nimmt alle Servo Pulse zurück außer den Puls für den Gaskanal.

Voreingestelltes Failsafe

Voreingestelltes Failsafe ist ideal für Segler Piloten und für einige Piloten mit Verbrenner Modellen.

Empfängerfunktion

Wenn nur der Empfänger eingeschaltet ist (Sendersignal liegt nicht vor), fahren alle Servos in der Regel auf neutral und das Fahrwerk wird ausgefahren, bis auf das Gas. Diese Positionen werden beim Binden im Empfänger gespeichert. Zu diesem Zeitpunkt gibt es kein Ausgangssignal am Gas, um das armieren eines Reglers zu verhindern. Bei Verbrennermodellen bekommt das Gasservo kein Signal und bleibt in der vorhandenen Stellung.

Verbindung

Wenn der Sender nach dem Einschalten sich mit dem Empfänger verbindet, funktionieren alle Servos normal. Geht das Signal verloren, werden alle Servos in die vorgesehene Fail Safe Position gefahren. Für Segler wird empfohlen, Klappen und Spoiler auszufahren, um ein Davonfliegen zu verhindern. Einige Piloten möchten eine leichte Kurve mit Schleppgas für das Fail Safe programmieren. Ist das Signal zurück, übernimmt das System sofort die Kontrolle (weniger als 4ms).

Programmierung SmartSafe (alle Spektrum Empfänger)

Der Bind Stecker verbleibt während des gesamten Bindungsprozess (Seite 14) im Empfänger. Er wird erst entfernt, wenn der Empfänger mit dem Sender verbunden ist, was durch Anlaufen aller Servos bestätigt wird. SmartSafe ist programmiert.

Programmierung Failsafe voreingestellt (nur AR9000 und AR9100)

Für den Bindungsprozess wird der Bind Stecker in die Ladebuchse des Schalterkabels oder den Batterieport des Empfängers gesteckt. Wird Strom eingeschaltet, blinken die LED an den Empfängern. Bevor Sie nun den Empfänger binden, ziehen Sie den Bind Stecker aus dem Empfänger wieder ab. Die LED blinken immer noch. Bringen Sie die Knüppel und Schalter in die gewünschte Fail Safe Position und schalten Sie den Sender mit gedrücktem Bindungsstecker ein. Innerhalb der nächsten 15 Sekunden wird die Bindung hergestellt. Der Empfänger ist auf voreingestelltes Fail Safe programmiert.

> ***Hinweis***. Die Failsafe Positionen werden über die Knüppel und Schalterstellung am Sender definiert.

Modul Sonderhinweis

Bevor Ihren neuen Modul übertragen kann, muss der Sender in PPM18 programmiert sein. Dies wird über das Menü Modulation eingestellt, welches Sie in der Anleitung der MC24 beschrieben finden.

Binden Sie jetzt den Empfänger (siehe Seite 14). Ihr System ist nun einsatzbereit.

Reichweitentest des Spektrum Moduls

Vor jedem Einsatz insbesondere mit einem neuen Modell, ist es wichtig, die Reichweite zu testen. Dieser Test wird mit dem Bindungsknopf am Modul durchgeführt. Durch Drücken des Knopfes wird die Sendeleistung reduziert, um den Test durchzuführen.

Reichweitentest des Moduls

1. Stellen Sie das Modell an den Boden und entfernen Sie sich 30 Schritte (28 m).
2. Wenden Sie sich dem Modell so zu, als würden Sie fliegen und drücken Sie den Bindungsknopf.
3. Sie sollten volle Kontrolle über das Modell haben.
4. Wenn Sie Probleme haben, wenden Sie sich an den Horizon Produkt Service:
   European Union: +49 4121 46199 66 (Deutschland)
   +44 1279 641 097 (United Kingdom)
   United States: 1-877-504-0233



Flight Log mit AR9000

Das Flight Log (SPM9540) mit Spektrum ist mit den Empfängern AR7000, AR7100, AR7100e, AR9000 und AR9100 kompatibel. Das Flight Log gibt Auskunft über die Güte des HF Links, den Empfang an den Antennen und die Daten der externen Empfänger. Zusätzlich wird die Empfängerspannung angezeigt.



Einsatz des Flight Logs

Stecken Sie das Flight Log in den Daten Port des Empfängers, bevor Sie diesen oder den Sender ausschalten. Das Display zeigt automatisch die Empfängerspannung i.e 6V2=6.2Volt.

Drücken Sie den Knopf für die folgenden Informationen:

A - Antennen Ausblendung Antenne A

B - Antennen Ausblendung Antenne B

L - Antennen Ausblendung linke externe Antenne

R - Ausblendung rechte externe Antenne

F - Frame Verlust

H - Hold

Antennen Ausblendung gibt den Verlust eines Bits an Information an der entsprechenden Antenne an. Es ist normal 50-100 Ausblendungen pro Antennen während eines Fluges zu haben. Wenn eine Antennen über 500 Ausblendungen im Flug aufweist, sollte die Antennen neu positioniert werden.

Frame Verlust ist die gleichzeitige Ausblendung aller Antennen zur gleichen Zeit. Der HF Link arbeitet optimal, wenn weniger als 20 Frame Verluste pro Flug auftreten.

Ein Hold stellt sich ein, wenn 45 Frames hintereinander verloren gehen. Wird ein Hold angezeigt, muss das gesamte System sorgfältig geprüft werden. Dabei müssen die Antennenpositionen genauso überprüft werden, wie der Sender und Empfänger selbst.

> ***Hinweis***: Sie können eine Servoverlängerung verwenden, um das Flight Log einzusetzen, ohne die Kabinenhaube öffnen zu müssen. In Modellen, in denen ausreichend Platz vorhanden ist, können Sie das Flight Log auch fest mit Doppelklebeband einbauen. Bei Hubschraubern erfolgt dies zum Beispiel am Hauptchassis.

EU-Konformitätserklärung

Konformitätserklärung gemäß Gesetz über Funkanlagen und Telekomunikationseinrichtungen (FTEG) und der Richtlinie 1999/5/EG (R&TTE)
Declaration of conformity in accordance with the Radio and Telecommunications Terminal Equipment Act (FETG) and directive 1999/5/EG (R&TTE)

Horizon Hobby Deutschland GmbH
Otto Hahn Str. 9a
D-25337 Elmshorn

erklärt das Produkt: Spektrum 9K Modulsystem mit AR9000 Empfänger (SPMMS2040)
declares the product:

Geräteklasse: 2
equipment class

den grundlegenden Anforderungen des § 3 und den übrigen einschlägigen Bestimmungen des FTEG (Artikel 3 der R&TTE) entspricht.
complies with the essential requirments of § 3 and other relevant provisions of the FTEG (Article 3 of the R&TTE directive).

Angewendete harmonisierte Normen:
Harmonised standards applied:

EN 60950-1:2001 + A11:2004	Gesundheit und Sicherheit gemäß § 3 (1) 1. (Artikel 3(1)a)) Health and safety requirments pursuant to § 3 (1) 1.(article 3(1)a))
EN 301 489-1 V1.6.1 (2005-09) **EN 301 489-17 V1.2.1 (2002-08)**	Schutzanforderungen in Bezug auf elektromagnetische Verträglichkeit § 3 (1) 2, (Artikel 3 (1) b)) Protection requirement concerning electromagnetic compatibility § 3 (1) 2, (article 3 (1)b))
EN 300 328 V1.7.1 (2004-11)	Maßnahmen zur effizienten Nutzung des Frequenzspektrums § 3 (2)(Artikel 3 (2)) Measures for the efficient use of the radio frequency spectrum § 3 (2) (Article 3 (2))

CE

Elmshorn, 01.07.2008

Jörg Schamuhn, Geschäftsführer
Managing Director

Deutschland	die USA	Kanada	Vereinigtes Königreich
Österreich	Spanien	Irland	Australien
Finnland	die Niederlande	Schweden	Dänemark

Garantie und Service Informationen

Warnung

Ein ferngesteuertes Modell ist kein Spielzeug. Es kann, wenn es falsch eingesetzt wird, zu erheblichen Verletzungen bei Lebewesen und Beschädigungen an Sachgütern führen. Betreiben Sie Ihr RC-Modell nur auf freien Plätzen und beachten Sie alle Hinweise der Bedienungsanleitung des Modells wie auch der Fernsteuerung.

Garantiezeitraum

Exklusive Garantie – Horizon Hobby Inc (Horizon) garantiert, dass das gekaufte Produkt (Produkt) frei von Material- und Montagefehlern ist. Der Garantiezeitraum entspricht den gesetzlichen Bestimmung des Landes, in dem das Produkt erworben wurde. In Deutschland beträgt der Garantiezeitraum 6 Monate und der Gewährleistungszeitraum 18 Monate nach dem Garantiezeitraum.

Einschränkungen der Garantie

(a) Die Garantie wird nur dem Erstkäufer (Käufer) gewährt und kann nicht übertragen werden. Der Anspruch des Käufers besteht in der Reparatur oder dem Tausch im Rahmen dieser Garantie. Die Garantie erstreckt sich ausschließlich auf Produkte, die bei einem autorisierten Horizon Händler erworben wurden. Verkäufe an dritte werden von dieser Garantie nicht gedeckt. Garantieansprüche werden nur angenommen, wenn ein gültiger Kaufnachweis erbracht wird. Horizon behält sich das Recht vor, diese Garantiebestimmungen ohne Ankündigung zu ändern oder modifizieren und widerruft dann bestehende Garantiebestimmungen.

(b) Horizon übernimmt keine Garantie für die Verkaufbarkeit des Produktes, die Fähigkeiten und die Fitness des Verbrauchers für einen bestimmten Einsatzzweck des Produktes. Der Käufer allein ist dafür verantwortlich, zu prüfen, ob das Produkt seinen Fähigkeiten und dem vorgesehenen Einsatzzweck entspricht.

(c) Ansprüche des Käufers – Es liegt ausschließlich im Ermessen von Horizon, ob das Produkt, bei dem ein Garantiefall festgestellt wurde, repariert oder ausgetauscht wird. Dies sind die exklusiven Ansprüche des Käufers, wenn ein Defekt festgestellt wird.

Horizon behält sich vor, alle eingesetzten Komponenten zu prüfen, die in den Garantiefall einbezogen werden können. Die Entscheidung zur Reparatur oder zum Austausch liegt nur bei Horizon. Die Garantie schließt kosmetische Defekte oder Defekte, hervorgerufen durch höhere Gewalt, falsche Behandlung des Produktes, falscher Einsatz des Produktes, kommerziellen Einsatz oder Modifikationen irgendwelcher Art aus.

Die Garantie deckt Schäden, die durch falschen Einbau, falsche Handhabung, Unfälle, Betrieb, Service oder Reparaturversuche, die nicht von Horizon ausgeführt wurden, aus. Rücksendungen durch den Käufer direkt an Horizon oder eine seiner Landesvertretung bedürfen der schriftlichen.

Schadensbeschränkung

Horizon ist nicht für direkte oder indirekte Folgeschäden, Einkommensausfälle oder kommerzielle Verluste, die in irgendeinem Zusammenhang mit dem Produkt stehen nicht verantwortlich, unabhängig ab ein Anspruch im Zusammenhang mit einem Vertrag, der Garantie oder der Gewährleistung erhoben werden. Horizon wird darüber hinaus keine Ansprüche aus einem Garantiefall akzeptieren, die über den individuellen Wert des Produktes hinaus gehen. Horizon hat keine Einfluss auf den Einbau, die Verwendung oder die Wartung des Produktes oder etwaiger Produktkombinationen, die vom Käufer gewählt werden. Horizon übernimmt keine Garantie und akzeptiert keine Ansprüche für in der folge auftretende Verletzungen oder Beschädigungen. Mit der Verwendung und dem Einbau des Produktes akzeptiert der Käufer alle aufgeführten Garantiebestimmungen ohne Einschränkungen und Vorbehalte.

Wenn Sie als Käufer nicht bereit sind, diese Bestimmungen im Zusammenhang mit der Benutzung des Produktes zu akzeptieren, werden Sie gebeten, dass Produkt in unbenutztem Zustand in der Originalverpackung vollständig bei dem Verkäufer zurückzugeben.

Sicherheitshinweise

Dieses ist ein hochwertiges Hobby Produkt und kein Spielzeug. Es muss mit Vorsicht und Umsicht eingesetzt werden und erfordert einige mechanische wie auch mentale Fähigkeiten. Ein Versagen, das Produkt sicher und umsichtig zu betreiben kann zu Verletzungen von Lebewesen und Sachbeschädigungen erheblichen Ausmaßes führen. Dieses Produkt ist nicht für den Gebrauch durch Kinder ohne die Aufsicht eines Erziehungsberechtigten vorgesehen. Die Anleitung enthält Sicherheitshinweise und Vorschriften sowie Hinweise für die Wartung und den Betrieb des Produktes. Es ist unabdingbar, diese Hinweise vor der ersten Inbetriebnahme zu lesen und zu verstehen. Nur so kann der falsche Umgang verhindert und Unfälle mit Verletzungen und Beschädigungen vermieden werden.

Fragen, Hilfe und Reparaturen

Ihr lokaler Fachhändler und die Verkaufstelle können eine Garantiebeurteilung ohne Rücksprache mit Horizon nicht durchführen. Dies gilt auch für Garantiereparaturen. Deshalb kontaktieren Sie in einem solchen Fall den Händler, der sich mit Horizon kurz schließen wird, um eine sachgerechte Entscheidung zu fällen, die Ihnen schnellst möglich hilft.

Wartung und Reparatur

Muss Ihr Produkt gewartet oder repariert werden, wenden Sie sich entweder an Ihren Fachhändler oder direkt an Horizon. Packen Sie das Produkt sorgfältig ein. Beachten Sie, dass der Originalkarton in der Regel nicht ausreicht, um beim Versand nicht beschädigt zu werden. Verwenden Sie einen Paketdienstleister mit einer Tracking Funktion und Versicherung, da Horizon bis zur Annahme keine Verantwortung für den Versand des Produktes übernimmt.

Bitte legen Sie dem Produkt einen Kaufbeleg bei, sowie eine ausführliche Fehlerbeschreibung und eine Liste aller eingesendeten Einzelkomponenten. Weiterhin benötigen wir die vollständige Adresse, eine Telefonnummer für Rückfragen, sowie eine Email Adresse.

Garantie und Reparaturen

Garantieanfragen werden nur bearbeitet, wenn ein Originalkaufbeleg von einem autorisierten Fachhändler beiliegt, aus dem der Käufer und das Kaufdatum hervorgeht. Sollte sich ein Garantiefall bestätigen wird das Produkt repariert oder ersetzt. Diese Entscheidung obliegt einzig Horizon Hobby.

Kostenpflichtige Reparaturen

Liegt eine kostenpflichtige Reparatur vor, erstellen wir einen Kostenvoranschlag, den wir Ihrem Händler übermitteln. Die Reparatur wird erst vorgenommen, wenn wir die Freigabe des Händlers erhalten. Der Preis für die Reparatur ist bei Ihrem Händler zu entrichten. Bei kostenpflichtigen Reparaturen werden mindestens 30 Minuten Werkstattzeit und die Rückversandkosten in Rechnung gestellt. Sollten wir nach 90 Tagen keine Einverständniserklärung zur Reparatur vorliegen haben, behalten wir uns vor, das Produkt zu vernichten oder anderweitig zu verwerten.

Achtung: Kostenpflichtige Reparaturen nehmen wir nur für Elektronik und Motoren vor. Mechanische Reparaturen, besonders bei Hubschraubern und RC-Cars sind extrem aufwendig und müssen deshalb vom Käufer selbst vorgenommen werden.

Europäische Union:

Elektronik und Motoren müssen regelmäßig geprüft und gewartet werden. Für Servicezwecke sollten die Produkt an die folgende Adresse gesendet werden:

Horizon Technischer Service
Otto Hahn Str. 9a
25337 Elmshorn, Germany

Bitte rufen Sie +49 4121 4619966 an oder schreiben Sie uns ein Email an service@horizonhobby.de um jede mögliche Frage zum Produkt oder der Garantieabwicklung zu stellen.

Sicherheit und Warnungen

Als Anwender des Produktes sind Sie verantwortlich für den sicheren Betrieb aus dem eine Gefährdung für Leib und Leben sowie Sachgüter nicht hervorgehen soll.

Befolgen Sie sorgfältig alle Hinweise und Warnungen für dieses Produkt und für alle Komponenten und Produkte, die Sie im Zusammenhang mit diesem Produkt einsetzen.

Ihr Modell empfängt Funksignale und wird dadurch gesteuert. Funksignale können gestört werden, was zu einem Signalverlust im Modell führen würde. Stellen Sie deshalb sicher, dass Sie um Ihr Modell einen ausreichenden Sicherheitsabstand einhalten, um einem solchen Vorfall vorzubeugen.

- Betreiben Sie Ihr Modell auf einem offenen Platz, weit ab von Verkehr, Menschen und Fahrzeugen.
- Betreiben Sie Ihr Fahrzeug nicht auf einer öffentlichen Straße.
- Betreiben Sie Ihr Modell nicht in einer belebten Straße oder einem Platz.
- Betreiben Sie Ihren Sender nicht mit leeren Batterien oder Akkus.
- Folgen Sie dieser Bedienungsanleitung mit allen Warnhinweisen sowie den Bedienungsanleitungen aller Zubehörteile, die Sie einsetzen.
- Halten Sie Chemikalien, Kleinteile und elektrische Komponenten aus der Reichweite von Kindern.
- Feuchtigkeit beschädigt die Elektronik. Vermeiden Sie das Eindringen von Wasser, da diese Komponenten dafür nicht ausgelegt sind.

Entsorgung in der Europäischen Union

Dieses Produkt darf nicht über den Hausmüll entsorgt werden. Es ist die Verantwortung des Benutzers, dass Produkt an einer registrierten Sammelstelle für Elektroschrott abzugeben diese Verfahren stellt sicher, dass die Umwelt geschont wird und natürliche Ressourcen nicht über die Gebühr beansprucht werden. Dadurch wird das Wohlergehen der menschlichen Gemeinschaft geschützt. Für weitere Informationen, wo der Elektromüll entsorgt werden kann, können Sie Ihr Stadtbüro oder Ihren lokalen Entsorger kontaktieren.



© 2008 Horizon Hobby, Inc.

4105 Fieldstone Road
Champaign, Illinois 61822
(877) 504-0233
www.horizonhobby.com
www.spektrumrc.com

Horizon Hobby UK, LTD.
Units 1-4 Ployters Rd.
Staple Tye, Southern Way
Harlow, Essex CM18 7NS
United Kingdom
+44 1279 641 097
www.horizonhobby.co.uk

Horizon Hobby Deutschland GmbH
Otto Hahn Strasse 9A
Elmshorn, Germany
+49 4121 46199 60
www.horizonhobby.de

13775

SPEKTRUM™



Air Module System for MC-24

SPEKTRUM™

Table of Contents

Introduction....3
Features and Benefits....4
Specifications....4
DSM Air modules. 4
Important Module Information 5
Antenna Installation (Internal) 6
Installing the Receiver....11
Installing the AR9000....12
Binding 14
How to Bind 14
Fail-Safe Functions....17
SmartSafe....17
Receiver Power Only 17
After Connection 17
Preset Fail-Safe....18
Receiver Power Only 18
After Connection 18
Programming SmartSafe(All Spektrum Aircraft Receivers)....18
Programming Preset Fail-safe(AR9000/9100 Spektrum Receivers) 18
Module Special Instructions 19
How to Range Test the Spektrum Module System....20
Range Testing the Module System....20
Flight Log—Optional for the AR9000....21
Using the Flight Log 21
FCC Information 22
Warranty and Service Information....24
Warning 24
Warranty Period 24
Limited Warranty....24
Damage Limits....24
Safety Precautions 25
Questions, Assistance, and Repairs 25
Inspection or Repairs 25
Warranty Inspection and Repairs....25
Non-Warranty Repairs....26
Contact Information 26
Safety, Precautions, and Warnings....27

Horizon Hobby is neither producer of nor distribution partner for MC-24 radios. We have independently developed our product as an add-on to the MC-24 radio and have tested the compatibility with the MC-24 radio.

The Spektrum trademark is used with permission of Bachmann Industries, Inc.

Introduction

Spektrum's Aircraft Module systems offer the ultimate in radio link security. No longer will you have to wait for an open frequency, or struggle with interference caused from noisy motors, ignition systems or other RF noise-generating sources. Spektrum's module systems utilize proprietary DSM2™ second generation Digital Spread Spectrum Modulation technology, providing an impenetrable radio link.

Operating within the ultra high frequency 2.4GHz worldwide ISM band, each module is programmed with its own unique serial code called GUID (Globally Unique Identification code). Once a receiver is programmed to a specific module (called binding), the receiver will only recognize and respond to that module ignoring signals from any other sources.

Spektrum's module systems are compatible with all Spektrum™ DSM2™ and JR™/DSM™ receivers (which excludes AR6000).

> ***Note***: The Module system is not compatible with the AR6000 first generation DSM receivers.
>
> ***Important***: When using the Module system with the AR6100 parkflyer receivers, it's imperative that this receiver only be flown in parkflyer type models. This includes all types of small electric airplanes and mini and micro helicopters. Do not fly the AR6100 receiver in large gas, glow or large electric aircraft as loss of control at extended range due to signal blocking issues can occur.

Features and Benefits

- Operates on the 2.4GHz ISM band allowing international use
- No more waiting for an open frequency
- Eliminates the possibility of interference from an unintentional turn-on
- Bulletproof interference rejection of all outside RF sources like cell phones, WiFi systems, other transmitters, etc.
- Impervious to model-generated RF interference (like noisy electric motors, metal-to-metal noise or ignition systems)
- No maintenance or tuning ever required
- Fail-safe system drives the throttle to preset position at loss of signal (see fail-safe options on page 17)

Specifications

DSM Air Modules

Frequency - 2.400–2.483GHz
Spectral capacity - 40 Systems
Type - Direct Sequence Spread Spectrum
DSSS coding gain - 18dB
Diversity - MultiLink: Path, Time and Frequency
Module current - 200mA
Receiver current - 70mA
Receiver voltage range - 3.5–9V DC
Servo channels - 9
Servo channel resolution - 1024 with 4X oversampling

Important Module Information

- Be sure the transmitter is in PPM18 modulation mode. If necessary, refer to the instructions included with your radio system for details on how to program your transmitter to PPM modulation. Note: The Spektrum module system will not operate in PCM modulation mode.

- Never power up the module unless the antenna is connected. Doing so can overload the module's electronics causing damage to the module.

- Before operating, the receiver must be bound to the module (see page 14 for binding instructions). Binding is the process of teaching the receiver the transmitter's specific GUID (globally unique identifier) code. Binding also sets the fail-safe positions. It's also recommended that the system be rebound again after radio setup to establish and confirm the desired fail-safe positions.

- Before each flying session, it's imperative that you do a range check (see page 20 for details) to confirm that the system is working properly.

- When using the Module system with the AR6100 parkflyer receiver, it's imperative that this receiver only be flown in parkflyer type models. This includes all types of small electric airplane and mini and micro helicopters. DO NOT fly the AR6100 receiver in large gas or glow aircraft as loss of control at extended range due to signal blocking issues can occur.

- The Module system features DSM2 technology and is compatible will all DSM2 compatible receivers. The Module system is not compatible with the AR6000 DSM first generation receiver.

Antenna Installation

1. Remove backplate.

2. Remove existing pin board (two screws).

3. Remove module tray (three screws).

4. Remove legacy antenna wire (red).



Antenna Installation

5. Remove antenna tension plate (three screws).



6. Remove legacy antenna assembly.



Antenna Installation

7. Install Spektrum 2.4GHz antenna assembly.



8. Install antenna tensioning washers (these can be adjusted to feel).



9. Reinstall antenna tension plate using two self-tapping screws and one tensioner screw.





Antenna Installation

10. Replace module tray.



11. Install new pin board.



12. Unplug JST connector from the old pin board and plug it into the new one.



13. Plug new Spektrum module into the module tray.



Antenna Installation

14. Connect Spektrum antenna.
Warning: Do not operate without antenna connected

15. Completed installation.



16. Replace with new supplied Spektrum backplate.

Installing the Receiver

The Module system is compatible with all Spektrum DSM2 and JR/DSM receivers including the AR500, AR6200, AR7000, AR7100, AR7100R, AR9000 and AR9100 full-range receivers as well as the AR6100, AR6100E and AR6300 parkflyer receivers.

PARKFLYER RECEIVERS



• AR6100 • AR6100E • AR6300

Note: An optional Flight Log (SPM9540) RF data recorder is available for the AR7000, AR7100, AR7100R, AR9000 and AR9100 receivers. The Flight Log records RF link flight data and displays this information onscreen, allowing you to evaluate the RF link performance of each individual receiver. See page 21 for more details about the optional Flight Log RF data recorder for the AR9000 receiver.

FULL RANGE DSM2 AIRCRAFT RECEIVERS



• AR6200 • AR7000 • AR9000



• AR7100 • AR7100R • AR9100

Installing the Receiver

Installing the AR9000

The AR9000 incorporates dual internal receivers, and one or two remote receivers offering the security of up to four simultaneous RF links for the ultimate in multi-path RF security. Two internal receivers are located on the main PC board, while a third remote receiver must be plugged into one of the antenna ports in order for the system to operate. Optionally, a second remote antenna can be plugged into the remaining remote antenna port giving a total of four operational receivers. By locating these receivers in different locations throughout the aircraft, each receiver is exposed to its own RF environment, greatly improving path diversity (the ability of the receiver to see the signal in all conditions).



Note: The AR9000 requires that at least one remote receiver be installed.

Install the main receiver using the same method you would use to install a conventional receiver in your aircraft. Typically wrap the main receiver in protective foam and fasten it in place using rubber bands or hook and loop straps. Alternately in electric or turbine-powered models, it's acceptable to use thick double-sided foam tape to fasten the main receiver in place.

Mounting the remote receiver(s) in a different location(s), from the primary receiver, gives tremendous improvements in path diversity. Essentially each receiver sees a different RF environment and this is the key to maintaining a solid RF link, even in aircraft that have substantial conductive materials, (i.e. turbine engines with metal tail pipes, carbon fiber, tuned pipes, etc.) which can attenuate the signal.

Using double-sided foam tape (servo tape), mount the remote receiver(s) keeping the remote antenna(s) at least 2 inches (51mm) away from the primary antenna. Ideally the antennas will be oriented perpendicular to each other, however, we've found this to not be critical. Leads of varying length are available (see table below), and in sophisticated aircraft we've found it best to mount the remote receivers in different parts of the aircraft, keeping the remote antennas as far away as practical from any conductive materials.

Remote Receiver Extensions

6-inch (152mm)	SPM9010
9-inch (228mm)	SPM9011
12-inch (305mm)	SPM9012
24-inch (610mm)	SPM9013
36-inch (914mm)	SPM9014

Installing the Receiver

A typical installation would include the main receiver mounted in the conventional location in the fuselage and the remote antennas in the nose (jets) in the top turtle deck and even in the tail. The optimum location is as far away from any conductive materials as is practical.



In helicopters, there is generally enough room on the servo tray to achieve the necessary separation.



If necessary, a mount can be made using clear plastic to mount the remote antenna as shown.



Binding

It's necessary to program the receiver to the specific module so that the receiver will only recognize that module, ignoring signals from any other sources. If the receiver is not bound to the module, the system will not operate. During binding the servo's fail-safe positions are stored.

The following sequence shows the binding procedure for the AR9000, however, all Spektrum aircraft receivers are bound in the same way.

How to Bind

The AR9000 receiver must be bound to the module before it will operate. Binding is the process of teaching the receiver the specific code of the transmitter so it will connect to that specific module. Once bound, the receiver will only connect to that module.

1. With the system hooked up as shown, insert the bind plug in the charge plug receptacle.



Note: When binding using a switch harness, a 3-wire switch harness must be used such as SPM9530.

Note: To bind an aircraft with an electronic speed controller that powers the receiver through the throttle channel (BEC), insert the bind plug into the battery port and proceed to Step #2.

Binding

2. Turn on the receiver switch. Note that the LED's on both receivers should be flashing, indicating that the receiver is ready to bind.



3. Establish the desired fail-safe stick positions: normally low throttle and flight controls neutral.

Binding

4. Press and hold the bind button on the back of the module while turning on the power switch. The bind button will flash and within a few seconds the system will connect. The LED's on the receivers will go solid, indicating the system has connected.

5. Remove the bind plug and store it in a convenient place.
6. After you've programmed your model, it's important to rebind the system so the true low throttle and neutral control surface positions are programmed.

Fail-Safe Functions

All of Spektrum's aircraft receivers feature a unique SmartSafe™ fail-safe system, while the AR9000 features two types of fail-safe: SmartSafe and preset fail-safe.

SmartSafe

This type of fail-safe is especially ideal for most types of electric aircraft and is also recommended for most types of gas- and glow-powered airplanes and helicopters. Here's how SmartSafe works.

> ***Note***: The AR500 throttle fail-safe position is stored via the throttle stick position on the transmitter.

Receiver Power Only

When the receiver only is turned on (no transmitter signal is present), all servos except for the throttle are driven to their preset fail-safe positions, normally control surfaces at neutral and the landing gear down. These fail-safe positions are stored in the receiver during binding. At this time the throttle channel has no output, to avoid operating or arming the electronic speed control. In glow-powered models, the throttle servo has no input so it remains in its current position.

After Connection

When the transmitter is turned on and after the receiver connects to the transmitter, normal control of all channels occurs. After the system makes a connection, if loss of signal occurs SmartSafe drives the throttle servo only to its preset fail-safe position (low throttle) that was set during binding. All other channels hold their last position. When the signal is regained, the system immediately (less than 4 ms) regains control.

> ***Note***: The AR500 removes servo output pulses to all channels except the throttle channel during fail-safe.

Preset Fail-Safe

Preset fail-safe is ideal for sailplanes and is preferred by some modelers for their glow- and gas-powered aircraft.

Receiver Power Only

When the receiver only is turned on (no transmitter signal is present) all servos except for the throttle are driven to their preset fail-safe positions, normally control surfaces at neutral and the landing gear down. These fail-safe positions are stored in the receiver during binding. At this time the throttle channel has no output, to avoid operating or arming the electronic speed control. In glow-powered models, the throttle servo has no input so it remains in its current position.

After Connection

When the transmitter is turned on and after the receiver connects to the transmitter, normal control of all channels occurs. After the system makes a connection, if loss of signal occurs preset fail-safe drives all servos to their preset fail-safe positions. For sailplanes it's recommended that the spoilers/ flaps deploy to de-thermalize the aircraft, preventing a flyaway. Some powered modelers prefer to use this fail-safe system to program a slight turn and low throttle to prevent their aircraft from flying away. When the signal is regained, the system immediately (less than 4 ms) regains control.

Programming SmartSafe (All Spektrum Aircraft Receivers)

During the binding process (see page 14), the bind plug is left in throughout the process and is removed only after the receiver connects to the transmitter. After the connection is made, confirmed by operating the servos, the bind plug can be removed. The receiver is now programmed for SmartSafe.

Programming Preset Fail-safe (AR9000 and AR9100 SPM Receivers Only)

During the binding process the bind plug is inserted in the bind port or in the charge jack (as shown on page 14), then the receiver is powered up. The LED's in each receiver should blink, indicating that the receiver is in bind mode. ***Now before binding the receiver to the transmitter and with the receiver in bind mode, remove the bind plug.*** The LED's will still be blinking. With the control sticks and switches in the desired fail-safe positions, bind the transmitter to the receiver by pressing and holding the bind buttons on the back of the transmitter/module and turning on the transmitter. The system should connect in less than 15 seconds. The receiver is now programmed for preset fail-safe.

> ***Note***: Fail-safe positions are stored via the stick and switch positions on the transmitter during binding.

Module Special Instructions

Before your new module can transmit, the radio must be placed in PPM18 mode. This is done in the modulation menu in your transmitter's programming. See your MC24 radio manual for specific details if necessary.

Bind the receiver to the transmitter. See page 14 for instructions on binding. Your system is now operational.

How to Range Test the Spektrum Module System

Before each flying session, and especially with a new model, it's important to perform a range check. The Spektrum Module systems incorporate a range testing system which, when the bind button on the module is pressed and held, reduces the output power, allowing a range check.

Range Testing the Module System

1. With the model resting on the ground, stand 30 paces (approx. 90 ft/28 m) away from the model.
2. Face the model with the transmitter in your normal flying position and depress and hold the bind button on the back of the transmitter. This causes reduced power output from the transmitter.
3. You should have total control of the model with the button depressed at 30 paces (90 ft/28 m).
4. If control issues exist, call Horizon Product Support for further assistance.
   United States: 1-877-504-0233
   European Union: +44 1279 641 097 (United Kingdom)
   +49 4121 46199 66 (Germany)



Flight Log—Optional for the AR9000

Spektrum's Flight Log (SPM9540) is compatible with Spektrum AR7000, AR7100, AR7100E, AR9000 and AR9100 receivers. The Flight Log displays overall RF link performance as well as the individual internal and external receiver link data. Additionally it displays receiver voltage.



Using the Flight Log

After a flight and before turning off the receiver or transmitter, plug the Flight Log into the Data port of the receiver. The screen will automatically display voltage i.e. 6v2= 6.2 volts

> ***Note***: When the voltage reaches 4.8 volts or less, the screen will flash indicating low voltage.

Press the button to display the following information:

A - Antenna fades on internal antenna A

B - Antenna fades on internal antenna B

L - Antenna fades on the left external antenna

R - Antenna fades on the right external antenna

F - Frame loss

H - Holds

Antenna fades—represents the loss of a bit of information on that specific antenna. Typically it's normal to have as many as 50 to 100 antenna fades during a flight. If any single antenna experiences over 500 fades in a single flight, the antenna should be repositioned in the aircraft to optimize the RF link.

Frame loss—represents simultaneous antenna fades on all attached receivers. If the RF link is performing optimally, frame losses per flight should be less than 20.

A hold occurs when 45 consecutive frame losses occur. This takes about one second. If a hold occurs during a flight, it's important to re-evaluate the system, moving the antennas to different locations and/or checking to be sure the transmitter and receivers are all working correctly.

> ***Note***: A servo extension can be used to allow the Flight Log to be more conveniently plugged in without having to remove the aircraft's hatch or canopy. On some models, the Flight Log can be plugged in, attached and left on the model using double-sided tape. This is common with helicopters, mounting the Flight Log conveniently to the side frame.

FCC Information

FCC ID: BRWDAMTX10
IC: 6157A-BRWDAMT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

> ***Caution***: Changes or modifications not expressly approved by Horizon Hobby, Inc. could void the user's authority to operate the equipment.

This product contains a radio transmitter with wireless technology which has been tested and found to be compliant with the applicable regulations governing a radio transmitter in the 2.400GHz to 2.4835GHz frequency range.

The following countries' associated regulatory agencies recognizing the noted certifications for this product as authorized for sale and use are:

USA	Canada	Denmark
Germany	Finland	Netherlands
Spain	Sweden	UK
Ireland	Austria	Australia

Declaration of conformity in accordance with the Radio and Telecommunications Terminal Equipment Act (FETG) and directive 1999/5/EG (R&TTE)

Horizon Hobby Deutschland GmbH
Otto Hahn Str. 9a
D-25337 Elmshorn

declares the product: Spektrum 9-Channel Module System (SPMMS2040)
equipment class: 2
complies with the essential requirments of § 3 and other relevant provisions of the FTEG (Article 3 of the R&TTE directive).

Harmonised standards applied:

EN 60950-1:2001 + A11:2004	Health and safety requirments pursuant to § 3 (1) 1.(article 3(1)a))
EN 301 489-1 V1.6.1 (2005-09) **EN 301 489-17 V1.2.1 (2002-08)**	Protection requirement concerning electromagnetic compatibility § 3 (1) 2, (article 3 (1)b))
EN 300 328 V1.7.1 (2004-11)	Measures for the efficient use of the radio frequency spectrum § 3 (2) (Article 3 (2))

CE

Elmshorn, 01.07.2008

Jörg Schamuhn, Geschäftsführer
Managing Director

Warranty and Service Information

Warning

An RC aircraft is not a toy! If misused, it can cause serious bodily harm and damage to property. Fly only in open areas, preferably at AMA (Academy of Model Aeronautics) approved flying sites, following all instructions included with your radio.

Keep loose items that can get entangled in the propeller away from the prop, including loose clothing, or other objects such as pencils and screwdrivers. Especially keep your hands away from the propeller.

Warranty Period

Exclusive Warranty - Horizon Hobby, Inc., (Horizon) warranties that the Products purchased (the “Product”) will be free from defects in materials and workmanship for a period of 1 year from the date of purchase by the Purchaser.

Limited Warranty

(a) This warranty is limited to the original Purchaser ("Purchaser") and is not transferable. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. This warranty covers only those Products purchased from an authorized Horizon dealer. Third party transactions are not covered by this warranty. Proof of purchase is required for warranty claims. Further, Horizon reserves the right to change or modify this warranty without notice and disclaims all other warranties, express or implied.

(b) Limitations- HORIZON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCT. THE PURCHASER ACKNOWLEDGES THAT THEY ALONE HAVE DETERMINED THAT THE PRODUCT WILL SUITABLY MEET THE REQUIREMENTS OF THE PURCHASER’S INTENDED USE.

(c) Purchaser Remedy- Horizon's sole obligation hereunder shall be that Horizon will, at its option, (i) repair or (ii) replace, any Product determined by Horizon to be defective. In the event of a defect, these are the Purchaser's exclusive remedies. Horizon reserves the right to inspect any and all equipment involved in a warranty claim. Repair or replacement decisions are at the sole discretion of Horizon. This warranty does not cover cosmetic damage or damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or modification of or to any part of the Product. This warranty does not cover damage due to improper installation, operation, maintenance, or attempted repair by anyone other than Horizon. Return of any goods by Purchaser must be approved in writing by Horizon before shipment.

Damage Limits

HORIZON SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCT, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY. Further,

in no event shall the liability of Horizon exceed the individual price of the Product on which liability is asserted. As Horizon has no control over use, setup, final assembly, modification or misuse, no liability shall be assumed nor accepted for any resulting damage or injury. By the act of use, setup or assembly, the user accepts all resulting liability.

If you as the Purchaser or user are not prepared to accept the liability associated with the use of this Product, you are advised to return this Product immediately in new and unused condition to the place of purchase.

Law: These Terms are governed by Illinois law (without regard to conflict of law principals).

Safety Precautions

This is a sophisticated hobby Product and not a toy. It must be operated with caution and common sense and requires some basic mechanical ability. Failure to operate this Product in a safe and responsible manner could result in injury or damage to the Product or other property. This Product is not intended for use by children without direct adult supervision. The Product manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup or use, in order to operate correctly and avoid damage or injury.

Questions, Assistance, and Repairs

Your local hobby store and/or place of purchase cannot provide warranty support or repair. Once assembly, setup or use of the Product has been started, you must contact Horizon directly. This will enable Horizon to better answer your questions and service you in the event that you may need any assistance. See page 26 for contact information.

Inspection or Repairs

If this Product needs to be inspected or repaired, please call for a Return Merchandise Authorization (RMA). Pack the Product securely using a shipping carton. Please note that original boxes may be included, but are not designed to withstand the rigors of shipping without additional protection. Ship via a carrier that provides tracking and insurance for lost or damaged parcels, as ***Horizon is not responsible for merchandise until it arrives and is accepted at our facility.*** A Service Repair Request is available at www.horizonhobby.com on the "Support" tab. If you do not have internet access, please include a letter with your complete name, street address, email address and phone number where you can be reached during business days, your RMA number, a list of the included items, method of payment for any non-warranty expenses and a brief summary of the problem. Your original sales receipt must also be included for warranty consideration. Be sure your name, address, and RMA number are clearly written on the outside of the shipping carton.

Warranty Inspection and Repairs

To receive warranty service, you must include your original sales receipt verifying the proof-of-purchase date. Provided warranty conditions have been met, your Product will be repaired or replaced free of charge. Repair or replacement decisions are at the sole discretion of Horizon Hobby.

Non-Warranty Repairs

Should your repair not be covered by warranty the repair will be completed and payment will be required without notification or estimate of the expense unless the expense exceeds 50% of the retail purchase cost. By submitting the item for repair you are agreeing to payment of the repair without notification. Repair estimates are available upon request. You must include this request with your repair. Non-warranty repair estimates will be billed a minimum of ½ hour of labor. In addition you will be billed for return freight. Please advise us of your preferred method of payment. Horizon accepts money orders and cashiers checks, as well as Visa, MasterCard, American Express, and Discover cards. If you choose to pay by credit card, please include your credit card number and expiration date. Any repair left unpaid or unclaimed after 90 days will be considered abandoned and will be disposed of accordingly.
Please note: non-warranty repair is only available on electronics and model engines.

United States:

Electronics and engines requiring inspection or repair should be shipped to the following address:

Horizon Service Center
4105 Fieldstone Road
Champaign, Illinois 61822

All other Products requiring warranty inspection or repair should be shipped to the following address:

Horizon Product Support
4105 Fieldstone Road
Champaign, Illinois 61822

Please call 877-504-0233 or e-mail productsupport@horizonhobby.com with any questions or concerns regarding this product or warranty.

European Union:

Electronics and engines requiring inspection or repair should be shipped to the following address:

Horizon Hobby UK
Units 1-4 Ployters Rd
Staple Tye, Southern Way 25337
Harlow, Essex CM18 7NS
United Kingdom

Please call +44 1279 641 097 or email sales@horizonhobby.co.uk with any questions or concerns regarding this product or warranty.

Horizon Technischer Service
Otto Hahn Str. 9a
Elmshorn, Germany

Please call +49 4121 46199 66 or email service@horizonhobby.de with any questions or concerns regarding this product or warranty.

Safety, Precautions, and Warnings

As the user of this product, you are solely responsible for operating it in a manner that does not endanger yourself and others or result in damage to the product or the property of others.

Carefully follow the directions and warnings for this and any optional support equipment (chargers, rechargeable battery packs, etc.) that you use.

This model is controlled by a radio signal that is subject to interference from many sources outside your control. This interference can cause momentary loss of control so it is necessary to always keep a safe distance in all directions around your model, as this margin will help to avoid collisions or injury.

- Always operate your model in an open area away from cars, traffic, or people.
- Avoid operating your model in the street where injury or damage can occur.
- Never operate the model out into the street or populated areas for any reason.
- Never operate your model with low transmitter batteries.
- Carefully follow the directions and warnings for this and any optional support equipment (chargers, rechargeable battery packs, etc.) that you use.
- Keep all chemicals, small parts and anything electrical out of the reach of children.
- Moisture causes damage to electronics. Avoid water exposure to all equipment not specifically designed and protected for this purpose.

Instructions for Disposal of WEEE by Users in the European Union

This product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or where you purchased the product.



© 2008 Horizon Hobby, Inc.

4105 Fieldstone Road
Champaign, Illinois 61822
(877) 504-0233
www.horizonhobby.com
www.spektrumrc.com

Horizon Hobby UK, LTD.
Units 1-4 Ployters Rd.
Staple Tye, Southern Way
Harlow, Essex CM18 7NS
United Kingdom
+44 1279 641 097
www.horizonhobby.co.uk

Horizon Hobby Deutschland GmbH
Otto Hahn Strasse 9A
Elmshorn, Germany
+49 4121 46199 60
www.horizonhobby.de

13775

SPEKTRUM™